

State of Missouri OA/Vehicle Maintenance Recommended Preventative Maintenance Schedule Light Duty Vehicles

This is a recommended preventative maintenance schedule that should apply to most passenger vehicles. Please note that the manufacturer's recommended schedule may differ from this schedule. Please contact your agency fleet manager or OA Vehicle Maintenance with any questions concerning appropriate maintenance for your vehicle.

PM 1: Every 5,000 miles OR 6 months (3,000 miles for heavy use vehicles)	
☐ Change Engine Oil & Filter	
Lubricate Chassis	
☐ Check/Top Off Fluid Levels	
 Transmission 	
 Differential 	
 Power Steering 	
o Brake	
 Windshield Washer 	
 Battery 	
 Radiator 	
Inspect & Rotate Tires, Check Tire Pressure (including Spare Tire)	
☐ Inspect & Replace If Necessary:	
 Wiper Blades 	
 Brakes (Pads, Shoes, Rotors/Drums, E 	3rake Lines, Hoses and Parking Brake)
Belts	
 Engine Cooling System and Hoses 	
Air Filter	
 Steering and Suspension Components 	;
 Exhaust System 	
 Exterior Lights 	
 Windshields (chip repair if necessary) 	
o CV Joints	
 Engine Coolant 	
PM 2 (Every 30,000 miles)	PM 3 (Every 60,000 miles)
☐ Inspect	☐ Inspect & Replace If Necessary
 Exhaust System & Heat Shields 	Spark Plugs (if equipped with
 Control Arm Bushings 	platinum plugs replace at 100,000 miles
 Wheels off inspection of all four 	– check owners manual)
brakes and components	o PCV
☐ Replace	o Timing Belt
Fuel Filter	☐ Clean
☐ Inspect/Change If Necessary	o Fuel Injectors
 Transmission Fluid 	 IAC and Throttle Body